

"PC-300-3-4-5"

Parts and Price List
(ILLUSTRATED)

MODELS

"PC-300-303-304-305"

300 WATT

Power-Charger

NOTICE

FILE IN SECTION 2 OF YOUR MOTOR
SERVICE MANUAL.

REMOVE AND DESTROY PRESENT
MODEL "PC-1" PARTS LIST (FORM MS-1682)
FROM SECTION 2 OF MANUAL.



TO FIND THE CORRECT NUMBER OF THE PART YOU NEED

1. Make a note of your motor TYPE NUMBER (Not the Serial Number) that appears on the metal nameplate attached to motor blower housing.
2. Refer to pages illustrating parts and locate the Master Part Number by comparing your old part with the illustrations. Assemblies include all part numbers bracketed in illustrations. All parts shown in assembly brackets on which part numbers are given can be purchased separately.
3. After the Master Part Number has been identified, refer to the following Parts Lists where these Master Part Numbers are listed in numerical order.
The Master Part is used on all models of motors except those types listed under "Note."
4. If a "Note" appears below the Master Part Number, this means that this part is made different from the Master Part for certain types and if your type is listed under "Note," order the part referred to.
5. If two or more parts are bracketed () under "note," they are used to replace the master part on the type numbers shown.
6. If your Motor Type Number does not appear after any part number listed under "Note," order the Master Part Number.
7. When ordering parts — or writing for service information — always specify the MODEL LETTER — TYPE NUMBER — and SERIAL NUMBER of your motor.

Parts List and Prices
MODEL "1" MOTOR

UNIT PARTS REQ.	MASTER PART NUMBER	NAME	SELLING PRICE EACH	UNIT PARTS REQ.	MASTER PART NUMBER	NAME	SELLING PRICE EACH
1	21110	Carburetor Venturi.....	.15	1	26228	Choke Lever Return Spring.....	.15
1	21119	Air Cleaner Elbow.....	1.75			Note: No. 26229 Spring.....	.05
1	21130	Carburetor Intake Elbow.....	.75			Used on type Nos. 206304, 206323, 206340,	
1	21277	Cam Gear	2.25			207005, 207009, 207012.	
1	21283	Top Compression Ring—Standard.....	.40	1	26235	Governor Link10
1	21310	Breather Body10	1	26265	Governor Spring35
1	21362	Cylinder Head	1.25	1	26330	Breather Spring05
1	21376	Top Compression Ring—.010" Oversize...	.40	2	26404	Stop Switch Washer.....	.05
1	21377	Top Compression Ring—.020" Oversize...	.40	1	26478	Exhaust Valve Spring.....	.20
1	21378	Top Compression Ring—.030" Oversize...	.40	1	26483	Stop Switch Spring.....	.15
1	22011	Valve Cover Plate.....	.15	1	27043	Base Gasket10
1	22025	Oil Baffle Plate.....	.10	1	27044	Cylinder Mounting Gasket.....	.05
1	22032	Needle Valve Packing Washer.....	.05	1	29667	Magneto Point Assembly.....	.75
1	22036	Carburetor Throttle Valve.....	.10	1	29671	Magneto Armature	3.00
1	22050	Carburetor Choke Valve.....	.10	1	29693	Spark Plug with Gasket (Champion No. J8).	.65
1	22082	Connecting Rod Screw Head Lock.....	.05	1	29739	Piston Assembly—Standard	2.90
1	22199	Oil Filler Cap Strap.....	.05	1	29778	Piston Assembly—.010" Oversize.....	3.40
1	22206	Cylinder Shield15	1	29779	Piston Assembly—.020" Oversize.....	3.40
1	22216	Breather Cover10	1	29780	Piston Assembly—.030" Oversize.....	3.40
1	22217	Oil Spray Shield.....	.10	1	29781	Piston—.010" Oversize	2.00
1	22233	Support Plate10	1	29782	Piston—.020" Oversize	2.00
1	22238	Cylinder Mounting Washer.....	.05	1	29783	Piston—.030" Oversize	2.00
1	22243	Cylinder Mounting Washer.....	.05	1	29806	Spark Plug Gasket.....	.05
1	22279	Carburetor Brace10	1	29835	Magneto Flywheel	6.00
1	22353	Valve Cover Washer..... 3 for	.05	1	29861	Condenser45
1	23059	Gas Shut-off Lever.....	.25	1	29878	Starter Rope25
1	23068	Speed Adjuster Nut.....	.10	2	37346	Rivet— $\frac{1}{8} \times \frac{1}{4}$ " Tubular, Speed Adjuster	
1	23069	Speed Adjuster Screw.....	.05			Mounting4 for
1	23114	Float Hinge Pin.....	.10			Washer, Armature and Contact Point	.05
1	23125	Throttle Stop Pin.....	.05	3	38852	Mounting3 for
2	23184	Valve Spring Retainer.....	.05			Spark Plug Shield Spring.....	.10
2	23187	Valve Spring Retainer Pin.....	.05	1	61756	Compression Ring—Standard40
1	23215	Baffle Plate Spacer.....	.10	1	61757	Oil Ring—Standard60
1	23222	Carburetor Nozzle50	1	61760	Flywheel Key10
1	23227	Needle Valve Packing Nut.....	.10	1	61768	Center Compression Ring—.010" Oversize	.40
1	23228	Idler Needle Valve.....	.25	1	61769	Center Compression Ring—.020" Oversize	.40
2	23230	Carburetor Throttle Bushing.....	.10	1	61770	Center Compression Ring—.030" Oversize	.40
1	23252	Choke Shaft20	1	61771	Oil Ring—.010" Oversize.....	.60
1	23292	Air Cleaner Bolt.....	.20	1	61772	Oil Ring—.020" Oversize.....	.60
2	23443	Locating Dowel Pin.....	.05	1	61773	Oil Ring—.030" Oversize.....	.60
1	23444	Valve Cover Stud.....	.05	1	61940	Generator End Plate.....	4.50
1	23612	Exhaust Valve	1.25	1	61967	Throttle Stop20
1	23692	Stop Switch Push Rod.....	.30	1	62473	Shim—.005" Thick05
1	26021	Intake Valve Spring.....	.05	1	62474	Shim—.010" Thick05
2	26026	Piston Pin Lock..... 3 for	.05	1	62577	Flywheel Washer10
1	26115	Crankshaft	4.75	1	62641	Speed Adjuster Plate.....	.05
2	26157	Idler Valve and Throttle Valve Spring....	.05	1	62693	Rope Starter Pulley.....	.45
1	26172	Pump Plunger Spring.....	.05	1	62835	Magneto Point Dust Cover.....	.15

U. S. A. PRICES. PRICES OUTSIDE OF U. S. A. SUBJECT TO LOCAL IMPORT DUTIES, TAXES, ETC.

"PC-300-3-4-5"

UNIT PARTS REQ.	MASTER PART NUMBER	NAME	SELLING PRICE EACH	UNIT PARTS REQ.	MASTER PART NUMBER	NAME	SELLING PRICE EACH
2	62842	Dust Cover Spacer.....	.05	1	90067	Screw—8—32x ⁵ / ₁₆ " Rd. Hd., Contact Point Mounting.....	.05
2	62851	Gas Tank Strap.....	.25	2	90079	Screw—10—32x ³ / ₈ " Rd. Hd., Tank Band Mounting.....	.05
1	62862	Stop Switch.....	.15	2	90083	Screw—10—32x ³ / ₈ " Rd. Hd., Tank Band Mounting.....	.05
5	62863	Cylinder Head Spacer.....	.3 for .05	1	90193	Screw—6—32x ³ / ₈ " Fill. Hd., Choke Stop... Note: No. 23270 Screw..... Used on type Nos. 206304, 206323, 206340, 207005, 207009, 207012.	.05
1	62876	Gas Filter Screen.....	.15	5	90200	Screw—8—32x ¹ / ₂ " Fill. Hd., Carburetor Body and Choke Lever Mounting.....	.05
1	62891	Spark Plug Wrench.....	.20	1	90202	Screw—10—32x ¹ / ₂ " Fill. Hd., Adjuster Screw Mounting.....	.05
1	63773	Piston Pin—Standard.....	.20	2	90313	Nut—8—32 Hex., Dust Cover Mounting...	.05
1	63782	Intake Valve.....	.50	2	90337	Nut—8—32 Hex., Stop Switch.....	.05
1	63785	Cam Shaft.....	.30	1	90362	Lockwasher—No. 6, Choke Stop..... Note: No. 22062 Lockwasher..... Used on type Nos. 206304, 206323, 206340, 207005, 207009, 207012.	.05
2	63788	Valve Tappet.....	.25	6	90366	Lockwasher— ⁵ / ₁₆ x ¹ / ₂ x ¹ / ₈ " , Generator Mounting.....	.05
1	63816	Piston Pin—.005" Oversize.....	.35	2	90369	Lockwasher— ¹ / ₂ x ³ / ₄ x ³ / ₃₂ " , Throttle and Choke.....	.05
1	63965	Oil Pump Plunger.....	.25	1	90699	Lockwasher— ¹ / ₄ x ³ / ₄ x ¹ / ₈ " Oil Pump Mtg.....	.05
1	65304	Oil Filler Cap Gasket.....	.05	14	90932	Lockwasher— ¹ / ₄ " , Blower, Base, and Intake Elbow Mounting.....	.05
1	65534	Filler Cap Gasket.....	.05	1	90847	Valve Cover Nut— ¹ / ₄ —28 Hex.....	.05
1	65704	Contact Point Plunger.....	.20	1	90877	Screw—8—32x ⁵ / ₈ " Rd. Hd., Stop Switch...	.05
1	65794	Armature Wrapper.....	.05	4	90916	Screw— ¹ / ₄ —20x ¹ / ₂ " Rd. Hd., Blower Mounting.....	.05
1	65968	Breather Disc.....	.05	6	90950	Screw—5/16-24x3/4" Hex. Hd. Generator Mounting.....	.05
2	66154	Washer— ¹ / ₈ " Thick, Fibre, Stop Switch...	.10	1	91287	Lockwasher— ¹ / ₂ x ³ / ₄ x ³ / ₃₂ " , Stop Switch.2 for	.05
1	66164	Washer— ³ / ₃₂ " Thick, Fibre, Stop Switch...	.10	1	91324	Washer, Cylinder Shield Mounting...2 for	.05
3	66432	Washer, Speed Adjuster and Tank Band Mounting.....	.05	4	91407	Lockwasher—13/64x1/16x3/64" Tank Strap	.05
1	67307	Magneto Plate Gasket—.015" Thick.....	.05	2	91419	Screw— ¹ / ₄ —20x ⁵ / ₈ " Hex. Hd., Pump Mounting.....	.05
1	67527	Valve Cover Gasket.....	.05	1	91456	Screw— ¹ / ₄ —20x1" Hex. Hd., Air Cleaner Elbow Clamping.....	.05
1	67537	Cylinder Head Gasket.....	.10	1	91488	Pipe Plug—1/8" Sq.....	.10
1	67597	Magneto Plate Gasket—.005" Thick.....	.05	1	91661	Lockwasher—11/64x3/64x3/64" Armature, Dust Cover, Carburetor Body.....	.05
1	67607	Magneto Plate Gasket—.009" Thick.....	.05	1	91708	Flywheel Mounting Nut.....	.05
1	68122	Camshaft Plug.....	.05	5	91711	Cylinder Head Screw— ¹ / ₈ —18x1".....	.05
1	68337	Base Gasket.....	.10	1	91712	Cylinder Head Screw— ¹ / ₈ —18x1 1/4".....	.05
1	68477	Gas Filter Gasket.....	.05	4	91753	Screw—8—32x1" Fill. Hd., Armature Mounting.....	.05
1	68487	Gas Filter Bowl.....	.15	8	91787	Screw—1/4-28x2" Hex. Hd. Base Mtg....	.05
1	68507	Felt Washer.....	.05	1	91811	Muffler Elbow Locknut.....	.05
1	68857	Carburetor Body Gasket.....	.10	2	91833	Dust Cover Stud.....	.05
1	68877	Inlet Valve Seat Gasket.....	.10	1	91920	Screw—8—32x ³ / ₈ " Fill. Hd., Throttle Adjusting.....	.05
1	68887	Needle Valve Packing.....	.05	1	91943	Muffler Elbow—90°..... Note: No. 91838 Muffler Elbow—45°..... Used on type Nos. 206304, 206323, 206340, 207005, 207009, 207012, 207033.	.40
1	68897	Venturi Gasket.....	.05	1	91984	Cotter Pin— ¹ / ₁₆ "x ¹ / ₂ " Tubular, Stop Switch.....	.05
1	68957	Air Cleaner Gasket.....	.05	2	92000	Screw—1/4-28x1-1/4" Hex. Hd. Oil Pump Mtg.....	.05
1	68987	Carburetor Mounting Gasket.....	.05	1	92017	Screw—8—32x ⁵ / ₁₆ " Fill. Hd., Choke Swivel.	.05
1	68997	Intake Elbow Gasket.....	.05	1	92067	Air Cleaner Wing Nut.....	.05
1	69345	Oil Filler Cap.....	.35	2	92084	Connecting Rod Screw.....	.05
1	89190	Gasoline Line—13" Long..... Note: No. 89226 Gasoline Line—11 1/2" long Used on type Nos. 206323, 207009.	.40 .35	2	92089	Screw— ¹ / ₄ —20x ³ / ₄ " Fill. Hd., Carburetor Mounting.....	.05
1	89362	Base.....	3.75	2	92125	Screw— ¹ / ₄ —20x ¹ / ₂ " Hex. Hd., Carburetor Elbow Brace.....	.05
1	89495	Upper Carburetor Body Assembly..... Note: Used on motors after Serial No. 69735.	3.50	4	92134	Screw—1/4-28x3/4" Hex. Hd. Magneto Mtg.....	.05
		No. 89735 Upper Body Assembly.....	4.50	8	92151	Lockwasher—1/4x3/32x3/64" Magneto & Carburetor Mounting.....	.05
		Used on motors before Serial No. 69735.		1	92171	Cotter Pin—3/32x1/4" long Filler Cap.4 for	.05
1	89624	Cylinder Assembly..... Note: No. 89727 Cylinder Assembly..... Used on earlier model motors using eight screws to mount cylinder to base.	12.00 12.00	2	92227	Lockwasher, Shakeproof, Cylinder Mounting.....	.05
1	89660	Oil Seal..... Note: Used on motors after Serial No. 55000.	.40				
		No. 23495 Oil Retainer Ring..... Used on motors before Serial No. 55000.	.20				
1	89677	Magneto Bearing and Oil Seal..... Note: Used on motors after Serial No. 55000.	.60				
		No. 89340 Bearing & Oil Ring..... Used on motors before Serial No. 55000.	.40				
1	89694	Choke Rod Assembly.....	1.40				
1	89708	Carburetor Assembly..... Note: No. 99876 Carburetor Assembly.... Used on type Nos. 206304, 206323, 206340, 207005, 207009, 207012.	7.50 7.50				
1	89742	Spark Plug Shield.....	2.50				
1	89769	Gas Tank Cap..... Note: No. 69221 Gas Tank Cap..... Used on type Nos. 206304, 206323, 206340, 207005, 207009, 207012, 207033, 207034.	.25 .15				
1	89838	Spark Plug Wrench.....	.50				
2	90029	Screw—4—36x ¹ / ₄ " Rd. Hd., Butterfly Mounting.....	.05				
1	90066	Screw—8—32x ¹ / ₄ " Rd. Hd., Condenser Mounting.....	.05				

U. S. A. PRICES. PRICES OUTSIDE OF U. S. A. SUBJECT TO LOCAL IMPORT DUTIES, TAXES, ETC.

Before ordering parts, read instructions top page 4.

"PC-300-3-4-5"

UNIT PARTS REQ.	MASTER PART NUMBER	NAME	SELLING PRICE EACH	UNIT PARTS REQ.	MASTER PART NUMBER	NAME	SELLING PRICE EACH
1	92235	Screw— $\frac{3}{8}$ —24x1 $\frac{1}{2}$ " Slot. Hd., Cylinder Mounting	.10	1	99732	Governor Blade Assembly	.50
1	92236	Screw— $\frac{3}{8}$ —24x2" Hex. Hd., Cylinder Mounting	.10	1	99739	Base (Cast Iron)	4.00
1	92291	Shut-off Lever Packing Nut	.10	1	99748	Piston—Standard	1.50
2	92294	Lockwasher— $\frac{1}{4}$ x $\frac{3}{8}$ x1 $\frac{1}{8}$ " Oil Pump Mounting	.05	1	99868	Throttle Lever	.50
1	92317	Lockwasher—Shakeproof Contact Mtg.	.05			Used on motors after Serial No. 69735.	
2	92451	Screw— $\frac{1}{4}$ —20x $\frac{3}{4}$ " Hex. Hd., Intake Elbow Mounting	.05			No. 89736 Throttle Lever	1.50
1	92542	Oil Drain Plug	.20			Used on motors before Serial No. 69735.	
1	99158	Ball Bearing	2.50	1	99874	Speed Adjuster	.35
1	99176	Ball Bearing Oil Seal	1.25	1	99879	Gas Filter Cover Assembly	1.00
1	99243	Carrying Handle	1.50	1	99955	Oil Pump Assembly	1.25
1	99390	Spark Plug Shield	1.25	1	290020	Ground Wire	.50
1	99391	Ignition Cable	1.25	1	290027	Blower Housing & Stop Switch	2.50
		Note: No. 99288 Ignition Cable	.15			Note: Screened—With Stop Switch—For Rope Starter Motors.	
		Used on type Nos. 206304, 206323, 207005, 207009.				No. 99179 Blower Housing	1.75
1	99621	Needle Adjusting Valve	.50			Screened—For Rope Starter Motors.	
1	99622	Carburetor Float	.35	1	290029	Muffler Assembly	1.50
1	99630	Air Cleaner Assembly	2.50			Note: No. 99193 Muffler Assembly	.75
1	99634	Upper Carburetor Body	2.00			Used on type Nos. 206304, 206323, 206340, 207005, 207009, 207012, 207033.	
1	99636	Inlet Valve and Seat	.50	1	290177	Oil Filler Cap Assembly	.75
1	99640	Connecting Rod Assembly	1.35	1	290341	Gas Tank Assembly	3.35
1	99665	Gas Filter Yoke Assembly	.50			Note: No. 99180 Gas Tank Assy	3.25
1	99678	Lower Carburetor Body	2.50			Used on type Nos. 206304, 206340, 207005, 207012, 207033, 207034.	
		Note: No. 21129 Lower Body	2.50			No. 99510 Gas Tank Assembly	8.00
		Used on type Nos. 206304, 206323, 206340, 207005, 207009, 207012.				Used on type Nos. 206323, 207009.	
1	99679	Choke Lever Assembly	.60			No. 89615 Shut-off Valve	1.60
		Note: No. 99700 Choke Lever Assy	.50			No. 99477 Gas Tank	6.50
		Used on type Nos. 206304, 206323, 206340, 207005, 207009, 207012.				No. 99509 Gas Line	.30
1	99714	Gasoline Filter Assembly	1.75			No. 99511 Tee Elbow	.50
				1	290365	Magneto Assembly	7.45
				1	290413	Oil Filler Cap & Gasket	.15
						Supersedes, and interchangeable with No. 61735.	

U. S. A. PRICES. PRICES OUTSIDE OF U. S. A. SUBJECT TO LOCAL IMPORT DUTIES, TAXES, ETC.

Before ordering parts, read instructions top page 4.

Generator

Parts List and Prices

UNIT PARTS REQ.	MASTER PART NUMBER	NAME	SELLING PRICE EACH	UNIT PARTS REQ.	MASTER PART NUMBER	NAME	SELLING PRICE EACH
2	22356	Washer Cutout Mounting.....	3 for .05	6	90781	Screw 8-32x $\frac{5}{16}$ " Fill Hd.....	.05
1	22561	Control Box	1.00	2	91661	Lockwasher— $\frac{1}{8}$ x $\frac{1}{4}$ x $\frac{3}{16}$ "	3 for .05
		Note: No. 62889 Control Box.....	.65	4	91697	Screw No. 6x $\frac{1}{4}$ " Sheet Metal.....	.05
		Used on type Nos. 25595, 25598, 25602, 25603.		2	91719	Lockwasher No. 6x $\frac{5}{16}$ x $\frac{3}{16}$ "	3 for .05
4	26082	Brush Staple10	1	91893	Screw $\frac{5}{16}$ -24x2 $\frac{1}{4}$ " Hex. Hd.....	.05
2	29759	Battery Clamp25	4	91895	Screw $\frac{1}{4}$ -28x1" Hex. Hd.....	.05
1	61945	Generator Shell	10.50	9	92290	Lockwasher No. 10.....	3 for .05
1	62897	Generator End Cover.....	2.50	2	92504	Screw—6-32x1/4" Rd. Hd.....	.10
1	62898	Pole Shoe Retainer.....	.30	4	99248	Generator Brush and Spring.....	1.45
1	65974	End Cover Grommet.....	.20	1	99249	Generator Fan	1.15
2	65984	Control Box Grommet.....	.10	1	99252	Brush Holder and Bracket Assembly.....	2.00
1	85196	Circuit Breaker	3.00	1	99255	Generator Field Coils—Set of 4.....	9.00
1	85759	Control and Starting Switch.....	3.00	4	99256	Generator Pole Shoe.....	.90
		Note: No. 80934 Starting Switch.....	3.00	1	99257	Generator Armature	20.00
		Used on type Nos. 25595, 25598, 25602, 25603.		1	99258	Lead Wire (Ground).....	.35
1	89963	Control Box Cover.....	.50	1	99259	Lead Wire (Switch to Generator).....	.35
		Note: No. 29750 Cover.....	.50	2	99260	Lead Wire (Switch to Circuit Breaker)....	.35
		Used on type Nos. 25595, 25598, 25602, 25603.		1	99261	Lead Wire (Generator Brush).....	.35
4	90079	Screw 10-32x $\frac{3}{8}$ " Rd. Hd.....	2 for .05	1	290164	Ammeter	2.00
2	90290	Nut 10-32 Hex.....	.05			Note: No. 99263 Ammeter.....	2.00
2	90310	Nut 6-32 Hex.....	.05			Used on type Nos. 25595, 25598, 25599, 25600, 25601, 25602, 25603.	
1	90366	Lockwasher— $\frac{5}{16}$ x $\frac{1}{8}$ x $\frac{1}{16}$ "	4 for .05	2	290207	Lead Wire (Positive and Negative).....	1.00
4	90528	Screw $\frac{1}{4}$ -28x $\frac{3}{4}$ " Hex. Rd.....	.05			Note: {No. 99250 Lead Wire (Positive)...	1.10
2	90596	Screw 10-32x $\frac{7}{16}$ " Rd. Hd.....	2 for .05			{No. 99251 Lead Wire (Negative)..	1.10
4	90699	Lockwasher 9-32x $\frac{5}{16}$ x $\frac{1}{16}$ "	3 for .05			Used on type Nos. 25598, 25599, 25600, 25601, 25602, 25603.	

U. S. A. PRICES. PRICES OUTSIDE OF U. S. A. SUBJECT TO LOCAL IMPORT DUTIES, TAXES, ETC.

Before ordering parts, read instructions top page 4.

Plate No. 21

